



StoveTop FireStop® Microhood™






StoveTop FireStop Microhood offers residences with over-the-range microwaves the same reliable, fully-automatic stovetop fire protection as our original StoveTop FireStop Venthood product. StoveTop FireStop is America's leading automatic stovetop fire suppressor with a 30+ year track record.

StoveTop FireStop Microhood dispenses fire suppressing powder to stovetops with lower clearances (15-24 inches above the cooking surface).

How does StoveTop FireStop Microhood work?

1. StoveTop FireStop Microhood attaches below microwave ovens or kitchen cabinetry. When flames from a grease fire on the front burner touch the bottom of the StoveTop FireStop Microhood, a link opens the front ramp mechanism (see graphic to the right).
2. Upon flame activation, the unit emits a short “pop” noise, alerting the resident that the device has activated. The petals of the StoveTop FireStop open, releasing the fire-suppressing powder.
3. The powder pours out via the ramp and suppresses the fire in the pan. After the fire is out (and if it is safe to do so), the resident should turn off the burner to prevent re-ignition. While the front ramp is designed to deliver the fire-suppressing powder directly to the front burner, a rear canister will deliver powder to the back burner if needed.





What else should I know about StoveTop FireStop Microhood?

StoveTop FireStop Microhood is easily attached to back walls made of gypsum board (drywall), tile, masonry or stainless steel. Also keep in mind:

- Industrial strength structural tape is included to fasten the product to a stainless steel backsplash. (Additional anchoring materials will be needed for tile or masonry walls.)
- StoveTop FireStop Microhoods are sold by the pair to protect a four burner stove. A single unit covers a front and back burner on one side of the stove.
- If you need to change a light bulb or replace vent filters, you can easily remove and reattach StoveTop FireStop Microhood from the wall-mounted bracket.
- StoveTop FireStop Microhood is non-pressurized, using only gravity to dispense its non-toxic powder onto the fire.
- Replace StoveTop FireStop Microhood every 5 years, or after activation.
- Not intended for deep-fat frying.
- StoveTop FireStop Microhood is currently available only in black.

