








# G450 / G460


## Quick Reference Guide

Power	Turn On	Press  .
	Turn Off	Press and hold  until "Switch Off" timer counts to zero.
Calibration	Fresh Air Calibration	Attach calibration adapter or press  and  simultaneously then press  . Make sure the atmosphere is fresh and free of contaminants.
	AutoCal <sup>®</sup>	Attach calibration adapter and press  . Apply gas and calibration will start automatically 30 sec. after  is pressed. Calibration takes approximately 45 sec.

# G450 / G460

## Quick Reference Guide

### Peak and Flashlight

Enable Peak	Press <b>PEAK</b> once. Peak icon 
Turn On Flashlight	Press and hold <b>PEAK</b> until beep sounds and button label changes to <b>LAMP</b> . Flashlight is an optional feature.
Enable Peak and Flashlight	First enable peak and then turn on the flashlight.
Reset Peak	Press <b>RESET</b> once.
Turn Off Flashlight	Press <b>LAMP</b> once.
Disable Peak	Press <b>PEAK</b> again, and icon turns off.